

xVision Video Converter – 3G-SDI series


Firmware Upgrade

- Firmware is upgradable in the field using the integrated USB port

How to proceed with the Firmware upgrade:


Step 1.

Open xvfwup.exe and connect to the unit using a USB to mini-USB cable.




Step 2.

Plug and un-plug the AC mains cable to power on/off the Converter (the connection check status will be changed to "Connect").




Step 3.

Plug and un-plug the AC mains cable again (the connection check status will be changed to “Connected”) and click the Open File button to select the firmware « .bin » file.



Step 4.

Click the “Start” Button to proceed with uploading the new firmware. The PASS message will appear when the process is successfully completed.



Step 5.

Close xvfwup.exe

